



COMPOUND MELTING POTS

General

Designed for melting capping compound, paraffin and similar materials, compound melting pots feature adjustable thermostat to deliver close temperature control automatically from 100 to 320°F (37.8 to 160°C). Includes cover, pilot light, 6' (1.8m) 3- conductor grounded cord set. Inner pot is cast aluminum encased in a metal jacket with fiberglass and air insulation, keeping heat loss to a minimum. Replaceable heating elements are securely clamped to the bottom and sides of the crucible for even heat distribution. Meets ASTM C617; AASHTO T231.

Operating Instruction

1. Carefully unpack and check for damage in shipping. Save original packing until set-up is complete. Notify Humboldt Mfg. Co. or your local agent and file a claim with any carriers involved if you find any damage to the melting pot.
2. Plug unit into an outlet that supplies the correct power (check tag for requirements).
3. If supplied with a timer:
 - a. Plug timer into outlet with correct power.
 - b. Set timer so that melting pot turns on 2 hours before arrival and turns-off at the end of the work day.
 - c. Never leave a melting pot unattended after desired melting point is achieved.
 - d. Plug melting pot into timer.
4. Consult supplier of material to be melted for the correct melting temperature. Do not set controls over that temperature.
5. Keep cover in place. This speeds the melting time and conserves electricity.
6. When using melting pot, wear protective eyewear and clothing.
7. If a problem or question should arise, contact the appropriate vendor.

Service Instruction

1. These melting pots have three basic circuit components:
 - a. Heating element which is factory service only.
 - b. Thermostat with 100 to 320°F range, SST bulb & capillary.
 - c. High limits: the 4-12 quart use 1, and the 20-28 quart use 2.
2. In-case of heating failure a test to ascertain the cause is:
If the heating light is on then the high limit (non-resetable fusible link) is open;
If the heating light is off the thermostat is open.
3. To replace the high limit, place the melting pot upside down, then
 - a. Loosen 5/16 nut.
 - b. Remove base from shell.
 - c. Locate thermostat sending unit under sheet metal clamp.
 - d. The high limit is also under this clamp.
 - e. Trim high limit wires 4" from either side of this clamp.
 - f. Loosen clamp and remove old high limits.
 - g. Replace with new high limits.
 - h. Connect the ends of wire with ceramic wire nuts provided.
 - i. Replace insulation and base.
 - j. Tighten nut.
 - k. Place into service.

Notes

- The high limit thermal fuse is set at 216°C, which is under the thermostat range.
- Leaving the pot on all day will degrade the hi-limit which otherwise has an expected service life of 2 years.
- Consult the factory for help if questions arise.

Capacity	Amps	Model	Shipping Wt.
4 qt.	6	H-2953	13 lbs
3.8L	3	H-2953.4F (220V 50/60Hz)	5.9 kg
8 qt.	10	H-2954	27 lbs
7.6L	5	H-2954.4F (220V 50/60Hz)	12.3 kg
12 qt.	11	H-2955	29 lbs
11.4L	5.5	H-2955.4F (220V 50/60Hz)	13.2 kg
20 qt.	12	H-2948	32 lbs
19L	6	H-2948.4F (220V 50/60Hz)	14.5 kg
28 qt.	15	H-2949	38 lbs
26.5L	7.5	H-2949.4F (220V 50/60Hz)	17.3 kg

Warranty

Humboldt Mfg. Co. warrants its products to be free from defects in material or workmanship. The exclusive remedy for this warranty is Humboldt Mfg. Co., factory replacement of any part or parts of such product, for the warranty of this product please refer to Humboldt Mfg. Co. catalog on Terms and Conditions of Sale. The purchaser is responsible for the transportation charges. Humboldt Mfg. Co. shall not be responsible under this warranty if the goods have been improperly maintained, installed, operated or the goods have been altered or modified so as to adversely affect the operation, use performance or durability or so as to change their intended use. The Humboldt Mfg. Co. liability under the warranty contained in this clause is limited to the repair or replacement of defective goods and making good, defective workmanship.

Humboldt Mfg. Co.

3801 North 25th Avenue
Schiller Park, Illinois 60176 U.S.A.

U.S.A. Toll Free: 1.800.544.7220

Voice: 1.708.456.6300

Fax: 1.708.456.0137

Email: hmc@humboldtmfg.com

Testing Equipment for



Construction Materials

HUMBOLDT

www.humboldtmfg.com