

**HM-9110, HM-9111****Asphalt Permeameter**

Directions for Use—(see ASTM Provisional PS-129-01 for procedure)

Position the two rear legs on an angle (45 degrees) and tighten the bolts. Attach the outflow pipe to the brass ball valve and tighten. The out flow pipe will then be positioned two inches (2.0") over the bottom of the sample pedestal.

Attach the two upright rods to the permeameter base by threading through the base and installing the nut from the bottom on each rod and tightening.

The piston on the front panel is used for drawing a vacuum on the membrane in order to position the membrane cylinder over the sample. Attach the tube from the cylinder to the VACUUM quick connect on the front panel and working the hand pump back and forth you will notice the membrane being pulled against the side wall of the container. This will allow you to place the container over the sample and pedestal. You will then position the top cap assembly into the container and over the sample. Note the two dished out pockets in the top cap are to be aligned with the nylon acorn nuts on the hold down clamp. The hold down clamp is then positioned to upright rods and the nuts tightened.

The two clamping screws on the clamp assembly are screwed down evenly until the large o'rings on the pedestal and top cap are expanded against the side wall of the latex membrane in the container.

The manometer tube is then placed through the clamp assembly and into the top cap. Please note there is an o'ring in the top cap. It may require extra effort (pushing down the manometer) to seat it properly through the o'ring. A lubricant is sometimes recommended on the end of the manometer tube.

The container tubing is then removed from the VACUUM quick connect on the front panel and attached to the PRESSURE quick connect. The membrane can then be pressurized using the hand pump. Keep in mind the gauge on the front panel is for reading positive pressure only. Please note the latex membrane is susceptible to damage and will leak if not cared for properly.

Humboldt Mfg. Co.

3801 North 25th Avenue
Schiller Park, Illinois 60176 U.S.A.

U.S.A. Toll Free: 1.800.544.7220

Voice: 1.708.456.6300

Fax: 1.708.456.0137

Email: hmc@humboldtmfg.com



Testing Equipment for

Construction Materials

HUMBOLDT

www.humboldtmfg.com