

SmartDCP User Guide (DOC-0073)

October 2015

Rev.1.0



www.humboldtmfg.com • 1.800.544.7220



SmartDCP



All rights reserved. No part of this manual may be reproduced, distributed, or transmitted in any form or by any means, including photocopying, recording, or other electronic or mechanical methods, without the prior written permission of the manufacturer: *Applied Research Associates 250 Beanville Rd Randolph, VT 05060*

The SmartDCP name, and all figures and information referencing the Smart DCP in this manual are copyright Applied Research Associates. Logos present on the DCP systems from Kessler and Salem Tool are copyright their respective owners. The use of Vertek, Kessler or Salem Tool DCP systems within this manual does not constitute a preference for these systems, the requirement to purchase these systems, or an implied increase of performance with these systems.



SmartDCP



Document Revisions

Date	Version Number	Document Changes
10/2015	1.0	Initial Draft of DOC-0073







Table of Contents

1	Welcome!5
2	First Time Users2
	2.1 Verify the Smart DCP Kit Contents2
	2.2Install the Smart Device Application
	2.3 Verify Range Finder Connectivity
	2.4Assemble the Hardware
3	Field Set-up and Data Collection4
	3.1 Data Acquisition
	3.2Forcing Data Collection
	3.3 Pausing a Test and Rod Changes8
	3.4 Deleting Data Point / Strike
4	Data Transfer11
	4.1 Transfer via E-mail
	4.2 Transfer via USB
5	Data Visualization12
	5.1 In-App Data Visualization
	5.2 Exported Data Visualization
6	Troubleshooting



1 Welcome!

Thank you for purchasing the new Vertek SmartDCP system! This innovative new product promises to reduce the training and manpower required to collect soil behavior data, while also improving accuracy and simplifying field logistics. The system achieves this by:

- Automatically counting blows
- Recording the change in depth with each blow
- Tracking the total depth of the probe
- Recording data on Apple iOS and Android smart devices via Bluetooth
 - Removing the need for a ruler, pencil, and paper
- Transferring data via e-mail or USB from the smart device

This user guide walks you through system operation. If you have any questions beyond what is covered in this material, please visit our website at <u>www.vertekcpt.com</u>, or call us at 1-800-639-6315.

2 First Time Users

This section provides the steps necessary to get the SmartDCP up and running. Be sure to complete these steps prior to entering the field.

2.1 Verify the Smart DCP Kit Contents

The SmartDCP is provided in a hard bottom toolbag with a shoulder strap so a single user can carry both the DCP itself, and our SmartDCP kit.

Caution: The SmartDCP kit contains a laser range finder labeled as a class 2 laser product. Do not stare into the laser.

Verify that the kit contains:

- 1. Carry Bag (DCP 0457)
- 2. Leica Disto E7100i Laser Range Finder with batteries (36753)
- 3. Baseplate with laser mount (DCP-0586)
- 4. Laser target (DCP-0588)
- 5. Smart device arm band (71200)
- 6. Stamped Wrench and 1" combination set (71192)
- 7. This manual (DOC-0073)



NOTE: The SmartDCP kit does not come with a smart device. The kit is intended to work with customers own devices with the free SmartDCP application.

2.2 Install the Smart Device Application

The SmartDCP application is designed to work with iOS and Android devices. The application interfaces with the laser range finder via the new 'Bluetooth Smart' communication system. This technology is available on Apple iPhones beginning with the 4S, and all Samsung Galaxy phones, among many other devices. For a complete list of compatible devices please see <u>http://www.bluetooth.com/Pages/Bluetooth-Smart-Devices-List.aspx</u>.

The smart device application can be found on the iOS App Store or Google Play. To find it, search for "Vertek", "Smart DCP" or navigate to the instructions below to download the application. The application is free and can be installed on as many devices as the user desires.

Apple iOS download Instructions: Select App Store Application

- 1. Search <u>Vertek or Smart DCP</u>
- 2. Select Smart DCP App and install



C Back			
VERTEK	Smart DCP Applied Resear	++) ch Associ	ates)
American			
Details	Hevrewith	Pied	ited
Detain	CP 💮	(B)	New Test
Detaris	CP 💽	Name	Now Test

Android download link:

https://play.google.com/store/apps/details?id=com.ara.vertek.smartdcp&hl=en

- 1. Select Google Play App on your Android smart device
- 2. Search Smart DCP
- 3. Select App and install



2.3 Verify Range Finder Connectivity

The steps shown graphically below will verify the user's smart device will interface with the laser range finder. Once verified, the system is ready for field use.



Select your newly installed SmartDCP application.



Begin a new test by selecting the '+' sign.



Give the test a name and select the 'Play' button then ensure range finder is on.



Wait for the 'Acquiring' message to disappear and verify the 3 vibrations/beeps indicating connection.

NOTE: The SmartDCP application uses vibrations and beeps to indicate various status conditions to the operator. These vibrations and beeps are tied to the volume control and vibration settings on the phone.

2.4 Assemble the Hardware

Hardware assembly is minimal for the Smart DCP system. The DCP Smart Laser Base Plate (DCP-0586) and DCP Laser Mount Bracket (DCP-0584) come pre-assembled by means of the Quick Release Mount Adapter (70939).

The user must install the DCP Smart Target Bushing (DCP-0588) onto the lower shaft of the manual system by sliding the bushing; flange first, onto the shaft until the flange contacts the coupling. Then slide the 5/8in Tube Fitting Ferrule (91176) onto the shaft with the tapered end facing the bushing, followed by the 5/8in Tube Fitting Nut (91174). Using the 1.0in combination wrench provided (71204) tighten nut ensuring that bushing cannot slide on shaft. It is recommended that this bushing become a permanent attachment only to be removed when a different lower shaft is needed for testing.



91176 Ferrule, 5/8 Tube Fitting

The installation of the DCP Smart ABS Target (DCP-0589) can be accomplished at the test site by sliding the target onto the bushing followed by the DCP Target Jam Nut (DCP-0590). The user can then use the two supplied 1-7/8in Stamped 7 Gauge Wrenches (71192) to ensure that the jam nut is tight enough to prevent the target from spinning on the bushing.



3 Field Set-up and Data Collection

Prior to entering the field, verify that all actions in Section 2 of this manual have been completed. The Smart DCP is designed for single operator use as indicated in the figure below:



3.1 Data Acquisition

To begin data acquisition, follow these steps:

- 1. Install Target disc onto bushing and ensure that Tube Fitting Nut is tight. Check rod sections and cone to ensure that they are tight.
- 2. Place DCP Smart Laser Base Plate with DCP Laser Mount Bracket and range finder attached, on surface in desired test location.
- 3. Place smart device containing the SmartDCP App into provided arm band, then place arm band in a convenient location for the user to see the data that will be acquired. Suggested location is the forearm of the upper shaft steadying hand.
- 4. Set cone on lower shaft into hole in DCP Smart Laser Base Plate, then drop weight until widest part of the cone is just below the test surface.

- 5. Turn range finding device on while ensuring shafts are perpendicular to test surface.
- 6. Begin a new test and carry out test as described graphically below.

A graphical step by step set of instruction is located on the following page (6-7) for iOS and Android devices.



Select your newly installed SmartDCP application.



Turn on and Select the desired range finding device in the settings.



A check mark or gray highlight will appear next to or over the selected device.



Name the test and select the 'Play' button.







System will 'Acquire' measurement device.



When measurement device is acquired smart device will vibrate/beep 3 times and test screen will appear as shown above.

	OS	And	roid
Vertzon 3G 10:	34 AM * => EST1 =	Smart DCP TEST1	0 4 at 1104
Name TEST1	<u> </u>	TRAINING TERTT	1
Upn. 43 70	ə.ə mm, 1a. i mm	CBR 14%	
CBR: 31 %	7.5 mm, 20.6 mm	CBR 15% 14.4 cun, 73.0 cum	
CBR: 30 %	7.6 mm, 35.1 mm	CBR 14%	
CBR: 33 %	7.0 mm, 42.1 mm	CBR 16%	
CBR: 31 %	7.5 mm, 49.6 mm	CBR 15%	
CBR: 35 %	6.7 mm, 56.3 mm	CBR 15%	
CBR: 35 %	6.6 mm, 68.3 mm	CBR 13%	

Collect data by lifting and dropping weight, smart device will vibrate/beep upon successful collection of each piece of data. The CBR percentage, penetration index and total depth will be displayed. User should wait for a successful data collection before proceeding with the next weight drop. When desired depth is met hit 'Stop' button to terminate test.



Confirm test termination by pressing the 'Yes/Ok' button. Once test is terminated the user may not return to test.

3.2 Forcing Data Collection

The SmartDCP system requires a minimum of 4mm of 'Penetration Index' or 'Delta' in order to successfully collect the data. When data is not successfully collected due to a refusal point the user is then able to 'Force' the SmartDCP system to collect a piece of data after a strike by pressing the 'Skip' button as shown graphically below.



When a hammer strike results in no data collected the user can force the system to collect data by pressing the 'Skip' button.



After the button is pressed the system will vibrate/beep 1 time and data will be collected that may be similar to that shown above. With a force the CBR% will range from 63% to 100% and the 'Penetration Index' or 'Delta' will range from 0 to 4mm.

3.3 Pausing a Test and Rod Changes

The SmartDCP system allows the user to easily pause a test to conduct other business; such as adding or removing a rod and this can be seen graphically below and page 9. When adding a rod its suggested to turn off the LRF, this action will not lose the test data.



To pause the test, in this case to add a rod, press the 'Pause' button.

To confirm the pause press the 'Yes/Ok' button button.

2)	ios	Andro	id
S Verizon 3G	9:57 AM 💲 🗩	R.Ø. ()	£ ₩ × 18 9.45
7	Paused	Smart DCP Paused	
Rome Ro	1 Change	Name Rod Durge	\sim
10.1 m (4.0.1	17.6 h (1 kg)	TT & IV (P Aut	
UDM. +1 70	16.1100,200.000	CBR 12%	
CBR: 10 %	20.6 mm, 316.6 mm	CBB 11%	
CBR: 10 %	21.0 mm, 337.6 mm	18.9 mm, 264.9 mm	
CBR: 10 %	19.9 mm, 357,5 mm	CBR 11% 19.4 mm, 304.3 mm	
CBR: 11 %	18.3 mm, 375.8 mm	CBR 10%	
CBR: 13 %	16.4 mm, 392.2 mm	CBD 0%	
CBR: 13 %	15.7 mm, 407.9 mm	20.0 mm, 548.4 mm	
CBR: 14 %	15.1 mm, 423.0 mm	CBR 8% 28.1 mm, 374.5 mm	
CBR: 13 %	15.7 mm, 438.7 mm	CBR 6%	

While the test is paused the user then changes the rod by removing the upper shaft with the striker. Then the user must remove the section of the lower shaft that contains the Target disc. The user then adds the rod extension, followed by re-attaching the lower shaft section with the Target disc, and finally the upper shaft with the striker. To continue the test, press the 'Play' button.



To confirm the continuation of the test press the 'Yes/Ok' button.

1	ios	And	Iroid		
Verizon 3G	9:58 AM 🕴 🚥	2.0	069	7.al	9:4
🖌 📂 В	od Change 📃	Smart DCP Rod Change		PP (
Name Ros	Change	Name Hod Chang	ŧ.		
10.1 0 14 0 1	02 07.4116 (0.54)	10.450 Map			1
UDH. 11 70	10.1.0001 \$90.0.000	CBR 12%			
CBR: 10 %	20.6 mm, 316.6 mm	CBR 11%			
CBR: 10 %	21.0 mm, 337.6 mm	18.9 mm, 294.9 mm			
CBR: 10 %	19.9 mm, 357.5 mm	CBR 11% 19.4 mm, 304.3 mm			
CBR: 11 %	18,3 mm, 375,8 mm	CBR 10%			
CBR: 13 %	16,4 mm, 392.2 mm	CBR 9%			
CBR: 13 %	15.7 mm, 407.9 mm	23.3 mm, 348.4 mm			
CBR: 14 %	15.1 mm, 423.0 mm	CBR 8% 25.1 mm. 374.5 mm			
CBR: 13 %	15.7 mm, 438.7 mm	CBR 6%			



3.4 Deleting Data Point / Strike

If you accidently record a data point after an undesired strike or depth change, you can delete the data point from the test. See the figures below or conduct the following: Select pause on the App, select the data point by holding your finger (long pressing) on the last data point, a pop-up will appear asking if you want to delete. Confirm by sliding your finger across (iOS) or selecting yes (Android) and the last data point will be deleted. Deselect the pause button on the App and return to testing.

-	11 >> 4	amw12	Smart DCP arriv11	
	Name anw	12	Same arrivel 1	
	10.7 8 (4.6 %	17.6 to 18 kgs		
	CBR: 16 %	13.5 mm, 13.5 mm	CBR 19% 11.5 mm, 11.5 mm	
	CBR: 15 %	13.8 mm, 27.3 mm	CBR 17%	
	CBR: 15 %	14.4 mm, 41.7 mm	CBR 17%	
	CBR: 15 %	14.3 mm, 56.0 mm	12.9 mm, 36.8 mm	
	CBR: 16 %	13.3 mm, 69.3 mm	CBR 16% 13.6 mm, 50.4 mm	
	CBR: 17 %	12.6 mm, 81.9 mm	CBR 17%	
	CBR: 19 %	11.4 mm, 93.3 mm	CBB 16%	
\neg	CBR: 0 %	412.7 mm, 506.0 mm	13.1 mm, 76.0 mm	
$\neg $			CBR 0%	





ios		Androi	id
+++>ii Verizon 30 1	122 AM 🖇 🗰 🔿	* 2 0	0 2 2 11:04
II ⊯ a	mw12	Smart DCP amw11	II >> II
Name ame	2	Name amin'1	
10.1 8 (4.6 kg	17.6 (b (3 kg)	CBR 19%	
CBR: 16 %	13.5 mm, 13.5 mm	11.5 mm, 11.5 mm	
CBR: 15 %	13.8 mm, 27.3 mm	CBR 17% 12.4 mm, 22.9 mm	
CBR: 15 %	14.4 mm, 41.7 mm	CBR 17%	
CBR: 15 %	14.3 mm, 56.0 mm	CBR 16%	
CBR: 16 %	13.3 mm, 69.3 mm	13.6 mm, 50.4 mm	
CBR: 17 %	12.6 mm, 81.9 mm	CBR 17% 12.5 mm, 62.9 mm	
CBR: 19 %	11.4 mm, 93.3 mm	CBR 16% 13.1 mm, 75.0 mm	
	Data point is	Data point is	
\leq	now deleted	now deleted	

4 Data Transfer

The user has two options for transferring the data from the smart device to other devices; by e-mail or via USB cable connected between the devices.

4.1 Transfer via E-mail



While at main screen press the 'Share' button.

Select the desired test for transfer and press the 'Mail' button.

4.2 Transfer via USB

To transfer via USB, connect the smart device to a computer with the appropriate USB cable for the device. For Apple iOS users, the computer must have iTunes installed in order to transfer data with a USB.

5 Data Visualization

5.1 In-App Data Visualization



On the main screen, select any test by tapping it.



CBR%* vs depth is shown first. Use the navigation buttons to change the plot.

*CBR% calculated using ASTM Standard: ASTM-D6951



The second plot, Delta, shows the change in depth per blow. Use the navigation buttons to change the plot.



The last plot shows the total depth at each blow. Use the 'X' to go back to the main menu.

5.2 Exported Data Visualization

A complimentary desktop application to organize and graph the DCP data is available for Windows systems. The program can be downloaded from a link on our product webpage http://www.vertekcpt.com/dcp-handheld-and-adcp or via electronic transmittal. The desktop application can be used to quickly graph your field data and keep your data organized using the application and windows explorer.

How to install the Smart DCP desktop application

Smart DCP Desktop	
officier of officier	VERTEN
Applied Research Associat	es, Inc.
Software License and Warr	anty
PLEASE READ THIS SOF	TWARE LICENSE
AGREEMENT CAREFULI	Y BEFORE OPENING

Select the executable file and terms and conditions will prompt you to agree.

\bigcirc	년 Smart DCP Desktop Setup	
		Welcome to the Smart DCP Desktop Setup Wizard
		The Setup Wizard will install Smart BCP Deaktop on your computer. Click Next to continue or Cancel to exit the Setup Wizard.
	REK	
	Vel	
		Back Next Cancel

Select the Install button, enter you administrator password and a set up wizard will appear, select: Next to continue.



An End User License Agreement and Warranty will appear, Accept and Select: Next.

(Λ)	Choose Setup Type	VERTEK
	Typical Installs the most common program features. Recommend Custom Allows users to choose which program features will be will be installed. Recommended for advanced users.	nded for most users.
	Camplete All program features will be installed. Requires the mos	t disk space. Hest Cancel

The installer will give you (3) options to install the application: Typical, Custom or Complete.

ack to review or change any of your installation
-

Select Install at the next prompt screen, after a few seconds, Select: Finish.



The Smart DCP Desktop application setup has been completed.



The Smart DCP Desktop application is stored in your user directory in the following breadcrumb trail with a desktop icon link:

(Example) C:\Users\John Doe\Documents\SmartDCP

How to install the Smart DCP desktop application

- 1. Select the executable file and terms and conditions will prompt you to agree
- 2. Select the Install button, enter you administrator password and a set up wizard will appear, select: Next to continue
- 3. An End User License Agreement and Warranty will appear, Accept and Select: Next
- 4. The installer will give you (3) options to install the application: Typical, Custom or Complete.
- 5. Select Install at the next prompt screen, after a few seconds, Select: Finish
- 6. The Smart DCP Desktop application setup has been completed

The Smart DCP Desktop application is stored in your user directory in the following breadcrumb trail with a desktop icon link:

(Example) C:\Users\John Doe\Documents\SmartDCP

How to use the Smart DCP Desktop application:



Double click the desktop application icon

2

Once open, select: File> Open>Data Folder

l	20151028152000	10/28/2015 4:02 PM	Microsoft Excel Co	2.%
	20151028152743	10/28/2015 4:02 PM	Microsoft Excel Co	4 K
	🖉 🍋 A1	7/30/2015 1:06 PM	Microsoft Excel W	20 K
	🔍 🏝 A2	7/30/2015 12:18 PM	Microsoft Excel W	22 K
	🕼 🕰 A3	7/30/2015 12:24 PM	Microsoft Excel W.,	21 K
	2 A4	7/30/2015 1:12 PM	Microsoft Excel W	20 K
	4) A5	7/30/2015 12:33 PM	Microsoft Excel W	19 K

Select your data files that you would graph and copy (Named by field user or date and time stamped).

3)	File View				
	 □ Data □ Data □ P a1 □ Field Data □ Test Data 	CBR Plot	Delta Plot Depth Plu		

Return to Smart DCP Desktop and select: View>Refresh

The selected data will transfer and appear in a directory structure underneath the File and View Commands. Select the test file and CBR graph will appear to the right.



Three graphical tabs can be instantly viewed.

Application graphs are plotted as a function of depth: CBR %, Delta (depth change between strikes) and Depth (total blows).









A Copy button is located in the bottom left corner.

Simply select the file and graph and select the copy button.

Open a Microsoft word document and paste and the graph will appear.

How to use the Smart DCP Desktop application

- 1. Double click the desktop application icon
- 2. Once open, select: File> Open>Data Folder
- 3. Windows explorer open the documents directory
- 4. Select your data files that you would graph and copy (Named by field user or date and time stamped)
- 5. Return to Smart DCP Desktop and select: View>Refresh
- 6. The selected data will transfer and appear in a directory structure underneath the File and View Commands
- 7. Select the test file and graph will appear
- 8. Three graphical tabs can be instantly viewed

Application graphs are plotted as a function of depth: CBR %, Delta (depth change between strikes) and Depth (total blows).

- 9. A Copy button is located in the bottom left corner
- 10. Simply select the file and graph and select the copy button
- 11. Open a Microsoft word document and paste and the graph will appear
- 12. If you would like to remove the data set from the desktop application select: File> Open>Data Folder and delete
- 13. The deleted data set will automatically be removed from the Desktop Application directory structure once refreshed (View>Refresh)
- 14. After reviewing the data, simply select File>Exit and application will close

If you encounter issues not addressed by this user guide, please contact your account manager for additional support.

6 Troubleshooting

- <u>Trouble pairing your smart device to laser range finder (LRF)</u>. It is not necessary to go into the smart device settings and search / pair the two Bluetooth devices. Simply, follow the steps on Page 2 of this manual, the smart device and LRF will automatically search for a connection when prompted. Smart Bluetooth doesn't require a manual pairing.
- Initial setup, during operation or after adding a rod to extend the DCP test penetration the LRF doesn't connect with the smart device. Make sure that when establishing the LRF to the target plate, the LRF base plate is as level as possible and the target is steady and in alignment with the LRF. Movement or misalignment can cause a LRF not to establish a reference distance.
- <u>The laser target slips down the DCP shaft.</u> Slide up the target and bushing to just below the hammer strike plate, verify the ferrule is seated and retighten with 1" combo wrench.
- <u>Measurement notifications (Beep or vibration) are slow to register.</u> Keep the target as level as possible over the LRF and make sure that the LRF lens is clean.



www.humboldtmfg.com • 1.800.544.7220